



Getting started: Coolpad Surf

Buttons and icons

There's a lot you can do with your new device, so here's a quick glance of some basic items to get you started.

Buttons



Power key: Hold the Power key for 3 seconds to power the device on/off. When the screen is off, press the Power key to turn the screen on.

WPS key: Hold the WPS key for 3 seconds to activate the WPS function. Once activated, the Wi-Fi™ LED indicator will flash every two seconds. If the network is not accessed within 2 minutes, the device will automatically exit WPS (Wi-Fi Protected Setup) mode.

LED indicators: Display network signal, Wi-Fi, SMS, battery charge and mobile data status.

First time use

Please take a look at the steps below to walk you through how to connect your hotspot:

1. Please refer to the back cover of your device to retrieve the Wi-Fi name (SSID) and Wi-Fi Password
 - The Wi-Fi name (SSID) will be "Coolpad Surf + the last 4 digits of IMEI"
 - The Wi-Fi password is the last 8 digits of the device IMEI
2. Hold the Power key for 3 seconds until all LED indicators illuminate in blue.
3. Connect your Wi-Fi device to your Mobile Hotspot.
4. On your computer or other Wi-Fi enabled device, search for available Wi-Fi networks and select network name (SSID) located inside the back panel of your mobile hotspot.
 - From a Windows PC:**
 1. Left-click Wireless Network Connection on the taskbar to view available networks.
 2. Choose the SSID from the list of available networks.
 - From a Mac computer:**
 3. Select **System Preferences > Network > Airport**.
 4. Click **Advanced** to choose SSID from the list of available networks.
 5. Choose the SSID from the list of available networks.
 - From an iOS device:**
 6. Go to **Settings > Wi-Fi**.
 7. Choose the SSID from the available networks.
 - From an Android device:**
 8. Go to **Settings > Wi-Fi settings**.
 9. Choose the SSID from the available networks.
5. Enter the password located inside the back panel, then click **OK**.

For Technical Assistance: T-Mobile Tech Support 844-341-4834



Comienso: Coolpad Surf

Botones e iconos

Su nuevo dispositivo tiene muchas funciones. Aquí tiene una guía de algunas de sus funciones básicas.

Botones



Boton de Encendido: Mantenga el boton de encendido oprimido por 3 segundos para encender y para apagar. Cuando la pantalla esta apagada precione el boton de ensendido para ensender.

Boton de WPS: Precione el boton de WPS por 3 segundo para activar la funcion the WPS. Ya activado, el indicador de Wi-Fi LED, pulsara cada 2 segundos. Si la red se no es accesible dentro de 2 minutos, el aparato se desconectara de WPS.

Indicador de LED: Indica la senal, Wi-Fi, SMS, carga de bateria y coneccion.

Primer Uso

Revise las instrucciones para seguir el proceso:

1. Anote el nombre de Wi-Fi (SSID) y la contraseña indicada en la etiqueta colocada frente a la cobertura exterior. Esta sera usada para el ingreso del primer uso. Si no tiene la etiqueta:
 - o El nombre de Wi-Fi (SSID) es "Coolpad Surf + los últimos 4 dígitos del número IMEI".
 - o La contraseña de Wi-Fi son los últimos 8 dígitos del número IMEI.
2. Asegurese que la tarjeta SIM y la batería están insertados.
3. Mantenga el boton de encender precionados por 3 segundos hasta ver que todas las luces de LED se ilimunen de color azul.
4. Conecte su aparato al dispositivo "Coolpad".
5. En su computadora o aparato electrónico, busque el Wi-Fi con el nombre indicado en el exterior de su dispositivo (SSID).

Uso de Windows PC:

1. Haga click derecho en Wireless Network Connection en la barra de tareas para ver las redes disponibles.
2. Seleccione SSID de la lista de redes disponibles.

Uso de computadora Mac:

3. Seleccione **System Preferences > Network > Airport**.
4. Haga click en **Advanced to choose SSID from the list of available networks**.
5. Seleccione SSID de la lista de redes disponibles.

Uso de aparato de iOS:

6. Seleccione **Setting > Wi-Fi settings**.
7. Seleccione SSID de la lista de redes disponibles.

Uso de aparato Android:

8. Seleccione **Settings > Wi-Fi settings**.
 9. Seleccione SSID de la lista de redes disponibles.
6. Ingrese la contraseña colocada dentro de la cobertura de su dispositivo y haga click en "OK".

Para Asistencia Técnica: T-Mobile Tech Support 844-341-4834